

# Araldite®

professional adhesives



## Araldite® Standard 24ml Syringe

A strong, solvent-free adhesive suitable for all materials, ideal for durable bonding and repairs. Perfect for complicated jobs which require adjustment thanks to a long working time.

### Important

Bonds metal, wood, masonry, ceramics, glass, dry concrete, chipboard, leather, cardboard, fabric, rubber and most plastics (except polyethylene, polypropylene, Teflon®). Make sure surfaces are clean and free from dust, corrosion, dirt and grease. For optimum bonding, slightly roughen surfaces with sandpaper and degrease metals with a suitable solvent. During assembly apply light pressure to the joint until set (clamps, tape) around 8 hours. Allow 14 hours to attain full strength before rough handling or sanding.

- Snap off the resealable cap from between the syringe plungers and break off the end seal. Depress the plunger to dispense equal amounts of both components onto a clean disposable surface. Re-fit the cap to close the nozzle.
- Mix thoroughly for at least 30 seconds until well mixed. Araldite® Standard remains usable for max. 90 minutes.
- Make sure both surfaces are clean and dry. Apply to both surfaces of the joint.
- Assemble carefully and remove any excess adhesive with a sharp blade once partially set.

### How to apply

Araldite® Standard is a strong 2-component epoxy with long working time. Parts repositionable for 80 minutes. Oil, chemical and impact resistant. High temperature resistance (-30°C to 65°C). Withstands rough handling. Do not use to repair or bond items that will contact food or drink. Not recommended for bonding rear-view mirrors to car windscreens.

### Storage

Should be stored in a dry place at room temperature in the original syringe.

### New

Environmentally friendly product formulation plus eco-friendly packaging for easy recycling.

Copyright® 2011. Huntsman Advanced Materials (Switzerland) GmbH. All Rights Reserved.

Uw specialist:

 Importeur  
VIBA NV | Bevestigen  
Blotwijkseweg 41  
2712 PB Zoetermeer  
Postbus 441  
2700 AK Zoetermeer

T +31 (0)79 330 67 20  
F +31 (0)79 330 67 95  
bevestigen@viba.nl  
www.viba.nl